



CFS-EPOXY PASTE INSTALLATION INSTRUCTIONS

Use of rubber gloves and safety glasses is recommended.

Mix epoxy paste, (1:1 ratio) on cardboard by using a paint stirrer or similar to mix until consistent.

OR

Mix in a small bucket with a mixing paddle or stirring stick until consistent.

Apply CFS-Epoxy Paste to surface defects as if you are spackling.

Use on vertical defects up to $\frac{3}{8}$ "

Use on horizontal defects up to +/- 2"

Pot life is up to 3 hours, depending on temperature. Tack free 5-10 hours.

After defects are patched, you can coat over CFS-Epoxy Paste immediately, even before it is cured, being cautious to not push the uncured paste out of the repair with a roller or a squeegee.

Coatings must be placed on top of this material within 24 hours of the initial patch, or you will need to sand the surface lightly to create a scratch for a good bond with the coating.

Cleanup as needed, using acetone, or a similar solvent.